

ph: 765.456.3957 fax: 765.456.3960

## www.CoanRacing.com

## INSTALLATION INSTRUCTIONS - COA-22812A T.H. 400 CLUTCH HUB, FORWARD (HEAVY DUTY)

To use this item machining to the Forward Drum must be completed.

Step Number 1 is for Steel drums only

- 1. Remove .060" from existing bearing surface. (Steel Drum Only)
- 2. counter bore from newly created surface 1.445/1.447 down to spline surface approx. .220
- 3. counter bore from same surface 1.500 down .060

